



## Concrete Column Skip

### Product information

With a range of sizes available, Concrete Column Skips are used for pouring concrete, especially in formwork or columns where access could prove to be difficult.



WLL ton	Capacity ltr	Weight kg	Delivery time
2.4	1,000	380	14
3.6	1,500	570	14