

## Standard Concrete Skip

### Product information

With a range of sizes available, Concrete Column Skips are used for pouring concrete, especially in formwork or columns where access could prove to be difficult.



Volume liter	Delivery time
500	2
1,000	2