



Standard Concrete Skip

Product information

With a range of sizes available, Concrete Column Skips are used for pouring concrete, especially in formwork or columns where access could prove to be difficult.

Volume liter	Delivery time
500	14
1,000	14